

# Boreal Complete Heat





## Un-packaging Instructions

For all models of BCH-1242

**Before un-packaging, inspect crate and contents for damage that may have occurred during shipping. Do not attempt to install the fire pit if any parts are damaged or missing.**

**\*\*At least two people are required for installation\*\***

1. Using a forklift place the crate as close as possible to the final installation location of your fire pit.
2. Locate and remove packaging straps securing the fire pit to the crate.
3. Remove ends and sides from the crate.
4. Use Included lifting straps to assist you in lifting the fire pit off of the crate and into the final position. Run the straps underneath the unit as shown below. Avoid the feet and the outlet tubes as shown in detail below. Take all precautions to prevent injury while moving the fire pit.



### Caution

Concrete top is not connected to the base, do not lift by the top. The weight of the unit should be bearing from the bottom of the unit through the strap to your forearms.



THE OUTDOOR  
GREATROOM  
COMPANY

[sales@outdoorrooms.com](mailto:sales@outdoorrooms.com) | 1.866.303.4028 | [outdoorrooms.com](http://outdoorrooms.com)